

1359 - Lip Topper (100.00g)

| Ingredient | Function | Percent | Wgt (g) | Wgt (oz) | Vol (tsp.) |
|---|-----------------------|----------------|----------------|-----------------|-------------------|
| Phase A | | | | | |
| Distilled Water (aqua) | Diluent | 74.70 | 74.70 | 2.63 | 14.94 |
| Glycerin (glycerin) | Humectant | 1.50 | 1.50 | 0.05 | 0.30 |
| Magnesium Aluminum Silicate (magnesium aluminum silicate) | Thickener | 1.50 | 1.50 | 0.05 | 0.30 |
| PVP (polyvinylpyrrolidone) | Film Former | 1.30 | 1.30 | 0.05 | 0.26 |
| Phase B | | | | | |
| Silky Talc Talc, Dimethicone | Texturizer | 2.00 | 2.00 | 0.07 | 0.40 |
| GelMaker EMU (sodium acrylate / sodium acryloyldimethyl taurate copolymer, isohexadecane, polysorbate 80) | Thickener, Emulsifier | 1.00 | 1.00 | 0.04 | 0.20 |
| Squalane (squalane) | Emollient | 1.50 | 1.50 | 0.05 | 0.30 |
| Caprylyl Glycol EHG (caprylyl glycol, ethylhexylglycerin) | Preservative | 1.00 | 1.00 | 0.04 | 0.20 |
| Phase C | | | | | |
| Mica Diamond Sparkle (mica [CI 77019], titanium dioxide [CI 77891]) | Colorant | 13.00 | 13.00 | 0.46 | 2.60 |
| Phenoxyethanol SA (phenoxyethanol, sorbic acid, caprylyl glycol) | Preservative | 0.50 | 0.50 | 0.02 | 0.10 |
| Mica Interference Copper (mica [CI 77019], titanium dioxide [CI 77891], silica) | Colorant | 2.00 | 2.00 | 0.07 | 0.40 |

Method

Combine phase A ingredients, heating to 50 C to help hydrate the Magnesium Aluminum Silicate. Stir thoroughly until PVP and Magnesium Aluminum Silicate is dispersed well and everything is homogenous. Cool to 40 C. Add phase B ingredients one by one in order, stirring well after each addition. Add phase C as desired. Viscosity can be adjusted with GelMaker EMU. Instead of interference copper another colored mica can be used if needed.

Properties

A beautiful, glittery lip topper to spruce up a lipstick or liquid lipstick or wear beautifully on it's own. Add lip balm on top to help seal in the glitter and prevent transfer.